



**BIG AL
TRADING**

DIY CAR STOP INSTALLATION

NB: Always plan your installation to avoid mistakes!

1. Drive the car to your desired parking spot in the garage
2. Position the Strip in front of both front tires
3. Move the car and draw with a pencil the outline around the Car Stop – at this point make sure it is positioned in a straight line.
4. Place masking tape around the pencil lines you have just marked. **DO NOT PUT TAPE TOO CLOSE TO PENCIL LINE, LEAVE A 2MM SPACE.**
(Wearing surgical / plastic gloves from this point on will ensure clean hands)
5. Clean and dry the area where you plan to install the Car Stop. All dirt, water, mud, oil and other debris must be removed. Wiping the area with benzene or lacquer thinners will ensure a clean bonding surface.
NB: Use personal protective equipment when using chemicals, i.e. gloves, mask, glasses etc.
6. Apply the adhesive to the floor using along each side and in a zigzag pattern through the middle
7. Press the strip onto the adhesive starting at one end, forcing out all air bubbles as you press down along the strip
8. Run a bead of adhesive along the edge of the door seal – use your finger dipped in soapy water so you can smooth the adhesive before it starts setting **(We recommend putting masking tape on the strip before running your bead to ensure a neat finish)**
9. Remove the masking tape before the adhesive sets. Wipe clean any excess with a cloth & lacquer thinners.

